

Always look straight on at the numbers on the dials, otherwise you could misalign them with the reference line - this could cause the lock to jam.















