



ACTIVATION CODE
CODE D'ACTIVATION
CÓDIGO DE ACTIVACIÓN

A

5440ENT/5441ENT Instructions/Instructions/Instrucciones

PRIMARY CODE
CODE PRIMAIRE
CÓDIGO PRINCIPAL

1

QR CODE
CODE QR
CÓDIGO QR

DEVICE ID
RÉFÉRENCE DE L'APPAREIL
IDENTIFICADOR DEL DISPOSITIVO

To get started, and for additional information, visit:
Pour commencer, et pour plus d'informations, visitez :
Para comenzar, y para ver información adicional, visite:
www.enterprise.masterlockvault.com

QUICK START – UNLOCK WITH MOBILE DEVICE


1. Remove lock box and instructions from package.
2. On your Android or iOS mobile device, visit the app store to download the Master Lock Vault Enterprise app. Before you launch the app, you must first set up an account, or have an existing account in order to add a new product.



- i. If you do not have an existing Master Lock Vault Enterprise account, you must create one at www.enterprise.masterlockvault.com.
 - ii. If you already have an existing account, please proceed to step 3.
3. Launch the Master Lock Vault Enterprise app and sign in.
 4. In the Master Lock Vault Enterprise app, touch the plus sign (+) in the upper-right corner.
 5. Scan the QR Code, from the gray box located above, on your mobile device to register the lock box. Once your lock box is registered, it will display in the Authorized tab inside the app. Touch the name of the lock box to access the lock box details, manage additional settings, and view the access history.
 6. By default, your lock box is in Wake Touch mode. To unlock the lock box, press any button on the keypad to wake it. The lock box will now appear under the Awake tab in the app. Touch the blue key icon to unlock the lock box. When the light turns green, open within 5 seconds or it will relock. The green light means the door can now be opened by pulling on it.

QUICK START – UNLOCK WITH LOCK BOX KEYPAD


1. Remove lock box and instructions from the package.
2. Enter the Primary Code, located in the black box above, into the lock box keypad. (Note: Do not pull on the door when entering the code and do not press the Clear button (See illustration 2). Entering the Primary Code will erase the Try Me code.)
3. When lock box light turns green, open within 5 seconds or it will relock.



Note: Pressing the Clear button erases all input and restarts the process.

QUICK START – REMOVE SHACKLE


1. Once you have downloaded the Master Lock Vault Enterprise app and registered your lock box, press any button on the lock box keypad to wake your lock box. The lock box will now appear under the Awake tab in the app. To remove the shackle, open the lock box details page by tapping the lock box name and then touch the Remove Shackle button. Your lock box will light green, and you can then remove the shackle within 5 seconds.
2. To remove the shackle using the lock box keypad:
 - i. Press the Clear button and first digit of your primary code, from the black box above, simultaneously (See illustration i).
 - ii. Release the Clear button and first digit, then enter the rest of the primary code.
 - iii. When the light turns green, remove the shackle within 5 seconds or it will relock.



Note: Pressing the Clear button erases all input and restarts the process.

BATTERY INSTRUCTIONS – HOW TO REPLACE BATTERY


1. Low battery will be indicated through an email notification, the app, or by a yellow light on the lock box.
2. Unlock and open the lock box door.
3. Using a Flat Head screw driver, open the battery compartment door and remove the battery.
4. Install a new CR123A battery, making sure to position the battery with positive and negative sides facing the proper direction as indicated on the door and battery compartment (See illustration 4).
5. Close the battery door and tighten the screw.



BATTERY INSTRUCTIONS – HOW TO UNLOCK WHEN THE BATTERY IS COMPLETELY DRAINED

1. If the battery drains while the lock box door is closed, you can jump it using an external 9-volt battery.
2. Locate the battery jump contacts on the bottom of the lock box (See illustration 2).
3. Hold a new 9-volt battery underneath the lock box with the positive (+) and negative (-) terminals pressed against the jump contacts (See illustration 3), in the orientation indicated on the bottom of the lock box (See illustration 2).
4. While holding the battery in place, and with an authorized mobile device within range of the lock box in Wake Touch mode, press any keypad button on the lock box. The lock box will now appear under the Awake tab in the app. Touch the blue key icon to unlock the box. If the lock box does not unlock, or an authorized mobile device is not available, enter the Primary Code on the lock box keypad, while holding the 9-volt battery in place.
5. When lock box is opened, install a new CR123A battery.

Note: After installing a new battery, the low battery icon will no longer display in the app after the lock box and app communicate with each other. However, it will take between 2 and 24 hours for the yellow LED to stop displaying on the lock itself.



Federal Communications Commission Notice: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications made to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Industry Canada Notice: This device complies with Industry Canada's license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference including interference that may cause undesired operation of the device.